

P/N (G2 DSL)

G2™ Driveshaft Loop Installation Instructions

(P/N G2 DSL)

Contents: (1) G2 Driveshaft Loop
(4) 3/8" x 1" Bolts
(4) 3/8" Washers
(4) 3/8" Locknuts

Tools /Supplies Required:

3/8" Socket
3/8" Open End Wrench
(4) Jack Stands
Floor Jack

Packed By: _____ Date: _____

The G2 Driveshaft Safety Loop is the finest available for 1993-98 Camaros and Firebirds. It is N.H.R.A. legal for cars requiring the installation of a driveshaft safety loop and it incorporates a g-load stiffening brace for added chassis strength. Thank you for selecting G2 Performance by Gigliotti!

Read Instructions Before Installing the G2 Driveshaft Loop!

1. Jack the car up and place 2 jack stands under the front frame and 2 under the axles
2. While underneath the car, remove the bolts holding on the factory stiffening brace located directly behind the transmission mount.
3. Slide the G2 round loop only over the driveshaft by the rear axle (make sure the angled side is towards the passenger side of the car)-See diagram below.
4. Slide the loop forward and stop where the factory stiffening brace used to be.
5. Now, take the flat G2 g-load brace and place it under the area where the factory stiffening brace used to be. Make sure the G2 g-load brace is installed with the bowed area facing down so it will clear the exhaust system, noting specific position of the driver and passenger side as shown in the diagram below.
6. Line up the G2 g-load brace with the G2 driveshaft loop and tighten the bolts. You may need to place a floor jack under the brace so that the G2 g-load brace bolts directly to the G2 driveshaft loop.
NOTE: the holes in the G2 driveshaft loop and g-load brace are larger than stock to take into account factory variations. Also, straightening of the factory stiffening brace location may require straightening due to factory variation
7. Your installation is now complete.

